



QUICK GUIDE

(Gratuity Setting & Tender)

Case 1



Back Office

Gratuity

Refund Includes Gratuity
 Check Tip Adjustment before Cashier-Out

Mandatory Gratuity Option:

Least Number:

Mandatory Gratuity (%):

Suggested Gratuity

1st Gratuity(%)	2nd Gratuity(%)	3rd Gratuity(%)
<input type="text" value="15.0"/>	<input type="text" value="18.0"/>	<input type="text" value="20.0"/>

Use Minimum Amount Suggested Gratuity

Minimum Amount:

1.type (points to Suggested Gratuity section)

2.tap (points to Save button)

3.tap (points to Refund Includes Gratuity checkbox)



Back Office

Settings

Store All POS devices may be run with the identical setting by using the store configuration.

<input type="button" value="Store"/>	<input type="button" value="Store Operations"/>	<input type="button" value="Tax Definition"/>	<input type="button" value="Printing Options"/>
<input type="button" value="Language"/>	<input type="button" value="User Defined Language"/>	<input type="button" value="Surcharge"/>	<input type="button" value="Gratuity"/>
<input type="button" value="Business Hours"/>	<input type="button" value="Cash Drawer Information"/>	<input type="button" value="Membership Accumulation Ratio"/>	<input type="button" value="Payroll Calculation"/>
<input type="button" value="User Defined Format"/>	<input type="button" value="Update Server Setting"/>	<input type="button" value="Backup Settings"/>	

tap (points to Gratuity button)



Printing Options

Receipt Print | **Customer Order Print** | Kitchen Order Print | Logo | Font Size | Other Settings

- Copy Count **1.tap**
- Message to Print [Max : 128]
 4.tap
- Order Bill Print for Dine In
 - When Check Out
 - When Order Menu

Print Sum of Qty
 Print Logo
 Print Barcode
 Print When Joining/Moving Table
 Print Multi-Menu Name (Secondary Name)
 Print Suggested Gratuity **2.tap**

3.tap

Save